

ez-Pro

VS4

H D S W I T C H E R

O P E R A T I O N

M A N U A L

LUMANTEK

Revision Number: 2.2.0
Distribution Date: March. 2019

Copyrights Notice

Copyright : 2006-2018 LUMANTEK Co., Ltd.
All Rights Reserved.

This document contains information that is proprietary to LUMANTEK CO., LTD. The information in this document is believed to be accurate and reliable; however, LUMANTEK assumes no responsibility or liability for any errors or inaccuracies that may appear in this document, nor for any infringements of patents or other rights to third parties resulting from its use.

This publication may contain technical issues, inaccurate information or typos. These will be revised in revised editions, if there is any. No part of this publication is subject to be reproduced, stored in retrieval system, or transmitted in any forms, or any means without prior consent by LUMANTEK.

Trademarks

HD ENCODULATOR TM, SD ENCODULATOR TM LUMANTEK Logo, Mega CruiserTM, ORIXTM, X-CruiserTM, DTA-PlusTM, Media BlasterTM, are Trademarks of Lumantek. Co., Ltd.

Any other trademarks than stated above in this document belongs to its pertinent corporation.

Warranty Period

Lumantek's products comes with One (1) year limited warranty. Please contact below if you need more information.

LUMANTEK CUSTOMER SERVICES

gs@lumantek.com

TEL : +82 - (0)2-6947-7400

FAX: +82 - (0)2-6947-7440

Installation Precautions

This page states the safety measures the users must take to avoid circumstances where the system may cause physical damages or injuries. Please THOROUGHLY go over this page before the system installation/operation.

General Precautions

- Maintain dust FREE condition during and after System Installation/Operation.
- Place the system cover in a safe location when opened.
- Securely stow tools and cables away from the passages.
- Avoid wearing loosened clothes or accessories during installation/Operation.
- Avoid any unnecessary actions that may damage/harm system or personnel.
- Do NOT open the system unless advised by Lumantek representative. Lumantek takes no responsibility on units with broken RMA seals.

Power Precautions

- Please check cable overload before connecting the system to the power supply.
- Avoid wearing metal accessories (Rings, Earrings) connecting system to the power source.
- Avoid operating on wet floors. Make sure power extension cables, floors, and instruments are grounded and in a safe operating condition.
- Discharge static electricity by touching grounding metals before starting hardware installation.
- The grounding parts must be disassembled last.
- Manufacture takes no responsibilities on Direct/Indirect losses or damages due to use of inappropriate parts or services by unauthorized service provider
- Supplying power during the system installation may cause damages to the system and personnel.

Contents

1. Introduction - 4CH Switcher VS4	07
2. Product Configuration	08
3. Interface	10
HDMI Multiview Layout Function Keys LED Screen	
4. Technical Terms	18
Background / Foreground Key Mode	
5. Screen	20
Program screen Multiview screen	
6. System Specifications	22

4CH Video Switcher

Introduction

Lumantek's ezStudio is an Audio & Video production brand developed by converging encoding and video switching technology suitable for small studios.

VS4 is a new product in ezStudio range, and a stand-alone type video switching console with integrated scaler.

The input resolution is scaled to system resolution and outputs 1 SDI and 1 HDMI channels. The "multiview" screen allows monitoring of a program (PGM) screen, preview (PVW) screen, and 4 input video sources. Each source is scaled and synchronized then controlled by the console.

Internal video processing: 4:2:2 10 bits or 4:2:2 8bits.

Audio: 4 video audio inputs (SDI/HDMI)
2 separate audio inputs

Features

1. Inputs & outputs

Input: 1 SDI
1 SDI / HDMI (select 1)
2 HDMI

Output: 1 SDI (PGM)
1 HDMI (PGM)
1 HDMI (Multiview)

2. Picture in Picture (PIP), Keyer (Chroma/Luma)


3. 3G-SDI levels A and B support in SDI inputs

2. Product Configuration

<Front>



<Rear>





Stand-alone
Video Switcher



Accessories




Manual




[S/W download]
(주소:<http://www.lumantek.com>)


3. Interface

HDMI Multiview Layout





① **Screen transition effects** : effects 0 to 17



② **Screen transition time (sec)**

0.5 /1.0 /1.5 /2.0 /2.5 /3.0

③ **System Resolutions**

1080p60/1080p59/1080p50/1080p30/1080p29/1080p25/

1080p24/1080p23/


1080i60/1080i59/1080i50/

720p60/720p59/720p50

④ **Input Resolutions**

3. Interface

Function Keys



Different functions are applied depending on the mode.

- SWITCHER mode : [SW]
- MENU mode : [ME]

① MENU key

(Menu button blinks while in Menu mode)

- [SW] - calls SWITCHER mode / resets sub-menu settings
- [ME] - calls MENU mode

② UP & DOWN keys

- [SW] - changes transition time
- [ME] - changes values in settings

③ SDI/HDMI keys

- [SW] - changes input channels between SDI and HDMI ports
- [ME] - changes sub-menu settings to their max. or min.
 - SDI key - Maximum value
 - HDMI key - Minimum value

④ FUNCTION keys

- PIP / LOGO1 / LOGO2 / LUMA & CHROMA keys :
 - [SW] - enable or disable functions
 - [ME] - go to functions menu
- AUDIO / SYSTEM keys :
 - [SW] - go to menu
 - [ME] - go to menu

⑤ SCREEN CONTROL keys

- Program (PGM) number keys
 - [SW] - selects input channels
 - [ME] - "alphabet" keys are activated for option selection
- Preview (PVW) number keys:
 - [SW] - selects input channels
- Fade to Black (FTB) key:
 - [SW] - fades the screen to black
- Take (TAKE) key:
 - [SW] - play transition
 - [ME] - applies changed settings (TAKE key blinks when changes are made but unsaved)

⑥ TRANSITION keys (played by pushing TAKE key)

- Wipe key:
 - [SW] - applies "wipe" transition effect
- Mix key:
 - [SW] - applies "mix" transition effect
- Cut key:
 - [SW] - applies "cut" transition effect
 - [ME] - reverses sub-menu selection or switches the system to SWITCHER mode

⑦ T-BAR


- Apply transition effect manually

⑧ LCD



MENU Screen

- Shows the version of the device



PICTURE IN PICTURE (PIP) Screen

[a] Src: Input source selection

[b] Size: In-picture size settings (10% ~ 50% of the screen size)

[c] Step: Units of pixels affecting effects of buttons [d] and [e]

[d] X: Horizontal displacement of In-picture screen

[e] Y: Vertical displacement of In-picture screen

(Upper-left corner of the screen has the coordinates 0,0)



LOGO1 & LOGO2 Screen

[a] Step: Units of pixels affecting effects of button [b] and [c]

[b] X: Horizontal displacement of the logo

[c] Y: Vertical displacement of the logo

(Upper-left corner of the screen has the coordinates 0,0)



Chroma Screen >>
 a : src : Input source selection
 b : Hue Pick : Go to "Hue Pick" menu
 c : Preset : Green H Gain/Blue H Gain/Green L Gain/Blue L Gain
 d : Hue : Go to "Hue" menu
 e : Sat : Go to "Sat" menu



[Chroma : Hue Pick]
 a : X : Horizontal displacement of src
 b : Y : Vertical displacement of src
 Hue : value of hue from X and Y
 f : Return : Go to previous menu



[Chroma : Hue]
 a : Center : Color setting for transparent foreground
 b : Width : Color range setting to make the foreground transparent
 c : Gain : Range setting for foreground translucent (0%-100%)
 f : Return : Go to previous menu



[Chroma> Sat]
 a : Min : Saturation range setting for foreground opaque
 b : Gain : Saturation range setting for foreground translucent (0%-100%)
 f : Return : Go to previous menu

Luma Screen >>



[Luma]


a : src : Input source selection

b : inv : Invert off/on setting

c : Transparency: Minimum transparency % of foreground

d : Min : Range setting for foreground opaque

e : gain : Translucent area setting of foreground
(100%:Only black is transparent,
0% largest translucent area





AUDIO Screen

- | | |
|--------------------|-----------------------|
| [a] In 1 | [a'] In 1 mute |
| [b] In 2 | [b'] In 2 mute |
| [c] In 3 | [c'] In 3 mute |
| [d] In 4 | [d'] In 4 mute |
| [e] External Input | [e'] External In mute |
| [f] Master | |

(Mixer concept audio control)
 (Volume controllable in units of 3dB)
 (Input sound can be identified on the "Multiview" Screen)
 (Volumes can be muted with respective keys on the "PVW" row.)
 Use the "WIPE" button to activate the AFV function.

[e] External Input

1. Tip : positive polarity for balanced mono signals
2. Ring : negative polarity for balanced mono signals
3. Sleeve : usually ground



SYSTEM Screen

- a : System resolution configuration
- b : Chroma, Luma menu selection
- c : Control of In-Audio (0dB, original sound / -10dB (10dB decreased))
- d : save
- e : load
- f : default

4. Technical Terms

Background / Foreground

Background



Foreground





Transparent

Semi-transparent



Opaque



CHROMA Key Mode



LUMA Key Mode




5. Screen

Program Screen

X and Y Coordinates (0,0) for PIP / LOGO1/ LOGO2



X and Y Coordinates (1920,1080) or (1280,720) for PIP/LOGO1/LOGO2



- ① Background Screen : Input 1/2/3/4
- ② Logo 1 : Max size : 1920 x 1080 (Alpha not supported)
- ③ Chroma/ Luma
Chroma : Used a lot in programs like weather broadcast
Luma : Used to apply power point screens
- ④ Logo 2 : Max size : 512 x 512 (Alpha supported)
- ⑤ Picture in Picture (PIP)
Insert a screen over another screen

** Logo (Logo1, Logo2)
File formats in bmp and png can be applied through USB2.0
Saved in the internal ROM.
(Please refer to 14 page.)



- **Multiview displays the audio status**

- Input screens: volume of each inputs are visible
- Preview (PVW): shows volume of “analog audio input”
- Program (PGM): shows volume of output program

- **Chroma / Luma / Logo1 /Logo2 are visible on the “Multiview” screen.**

- PIP / LOGO1 / LOGO2 are visible as a rectangle frame on the Multiview screen while changing position
- HuePick icon appears while using “Hue Pick” option of the “Chroma” Menu (PIP is not available on the “Multiview” screen.)

4x1 Video Switcher with Scaler

Input

Video Input : SDI(BNC 75Ω) x2, HDMI x3

Analog Audio Input : 6.35mm(1/4") Phone Jack(Balanced) x 2
±10V (Max) @ -10dB

Output

Video Output(PGM) HDMI x1, SDI(BNC 75Ω)x1

Multiview Output : HDMI x1

Analog Audio Output : 3.5mm Stereo Jack x 1

Key

- PIP x 1

- LOGO x 2

- CHROMA/LUMA x 1

Internal Processing : 4:2:2 10bits/8bits

Resolution supported

Input

- SD : 480i59/ 576i50/

- HD : 1080p30/1080p29/1080p25/1080p24/1080p23/
1080i60/1080i59/1080i50/720p60/720p59/720p50

- Full HD : 1080p60/1080p59/1080p50

Output

- HD : 1080p30/1080p29/1080p25/1080p24/1080p23/
1080i60/1080i59/1080i50/720p60/720p59/720p50

- Full HD : 1080p60/1080p59/1080p50

Management

Console

USB2.0 @ GUI application, Firmware Upgrade, LOGO Update

Physical

Dimension : 70(H) X 297(W) X 230(D) mm (excluding connectors)

Power Input : DC 7 - 14V

Operation Temperature : 0 - 40°C

Power Consumption : 20W(max)

Weight : 1.7Kg

LUMANTEK CUSTOMER SERVICES

gs@lumantek.com

TEL : +82 - (0)2-6947-7422, 7429

FAX : +82 - (0)2-6947-7440